




2025 CORN PLANTABILITY RESOURCE

Optimal planting accuracy and stands can be achieved with all seed sizes when using appropriate planter adjustments and calibration. Learn how to utilize our seed corn plantability tool to improve planting.

For the most precise recommendations, you can access information for individual seed batch numbers with the QR code to the right or by visiting <https://plantability.pagcat.com/h>



Scan Here



Entering Batch-Specific Plantability Information

Firstly you will enter the batch number that can be found on seed tag (outlined as #1 on the graphic) and your planter (#2). The website will then populate a customized list with the plate or disc size (#3), pressure or vacuum setting (#4), RPM (#5), and the singulator setting (#6), in addition to the predicted seed drop for each individual batch and planter combination (#7).

Use recommended planter settings as a starting point to maximize planter performance and seed-drop accuracy. Further settings adjustments may be made to account for local field conditions and environmental factors.

HOEGEMEYER
THE RIGHT SEED.

Your Plantability

Improve your planting accuracy and get the most from your investment in seed. Enter a comma separated list of batch numbers, optionally select the make and type of your planter(s) from the list and click "Go".

6649954 **1** JD VACUUM **2** Go

Where do I find the Batch Number?

Batch	Product	Make	Type	Kernel Size	Plate/Disk	Pres/Vac	RPM	Singulator/Brush	Seed Drop
6649954	8054V	JD	VACUUM	ER1	A92777	25	40		1.002
6649954	8054V	JD	VACUUM	ER1	PROMAX 40 A52391	14	20	6	1.001
6649954	8054V	JD	VACUUM	ER1	R-A50617 3	12 4	38 5	6 6	1.006 7
6649954	8054V	JD	VACUUM	ER1	S-A43215	18	38		1

FOR COMPLETE DETAILS, CONTACT YOUR HOEGEMEYER REPRESENTATIVE OR CALL 1.800.AG LINE 1 (1.800.245.4631)

©2025, Hoegemeyer Hybrids. Hoegemeyer® is a registered trademark of Hoegemeyer Hybrids.



HOEGEMEYER
THE RIGHT SEED.